MOUNTING INSTRUCTION

BODY CLADDING INSTALLATION INSTRUCTIONS
NOTES:

- *PLEASE ENSURE THE SURFACE IS NON POROUS, CLEAN, DRY AND SMOOTH BEFORE APPLICATION. PLEASE DO NOT TOUCH AFTER THE LINE HAS BEEN REMOVED.*

- *DO NOT WASH YOUR VEHICLE 24 HOURS AFTER INSTALLATION.*

- *IF YOU ARE SURE THE SURFACE IS CLEAN, APPLY THE 3M PRIMER WIPES TO THE SURFACE DO NOT INSTALL IN RAINY WEATHER.*

TOOLS REQUIRED:

-TAPE
-PRIMER HANDKERCHIEF

BODY CLADDING INSTALLATION INSTRUCTIONS

FIRST, THE VEHICLE SURFACE IS CLEANED. THEN THE CLEAN VEHICLE SURFACE IS WIPED WITH A PRIMER WIPE. THE RED TAPE LABEL INSIDE THE PART IS REMOVED AND ADHERED TO THE CLEAN VEHICLE SURFACE.



LEFT BODY CLADDING

CLEAN THE VEHICLE SURFACE. TAKE THE PART THAT SAYS LEFT BODY CLADDING ON THE PRODUCT INNER LABEL. TEST THE PRODUCT ON THE VEHICLE WITHOUT REMOVING THE LABELS. AFTER THE TRIAL, REMOVE THE RED TAPE LABEL INSIDE THE PRODUCT. STICK IT ON THE CLEAN VEHICLE SURFACE.





RIGHT BODY CLADDING

CLEAN THE VEHICLE SURFACE. TAKE THE PART THAT SAYS RIGHT BODY CLADDING ON THE PRODUCT INNER LABEL. TEST THE PRODUCT ON THE VEHICLE WITHOUT REMOVING THE LABELS. AFTER THE TRIAL, REMOVE THE RED TAPE LABEL INSIDE THE PRODUCT. STICK IT ON THE CLEAN VEHICLE SURFACE.



ONEWAY